

Fast Pulse Converter, PN 1036A, Excel Corp jumper settings for Ultratech stepper

	1	2	3	4	5	6	7	8
Axis 1	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Axis 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Q1	OFF	OFF	na	OFF	na	na	na	ON
Q2	OFF	OFF	na	OFF	na	na	na	ON
N	OFF	ON	na	OFF	na	na	na	ON
P	OFF	OFF	na	OFF	na	na	na	ON
D					ON	ON (reads "4" on the board)		