If you have answered yes to all of the questions, your HP-ID-Module can be replaced by the SYSKOMP-ID-BOX and can be checked immediately. Carry out the following 11 steps:

- 1. Shut down your system (HP-UX users) and switch the computer off.
- 2. Switch the toggle-switch at the front panel of the SYSKOMP-ID-BOX into the right ("Normal") position.
- 3. Remove the cable end marked with two dots from the HP-ID-Module and plug it into the left receptacle of the SYSKOMP-ID-BOX, also marked with two dots.
- 4. Remove the cable marked with one dot from the HP-ID-Module and plug it into the right receptacle of the SYSKOMP-ID-BOX, also marked with one dot. Now the SYSKOMP-ID-BOX is connected.
- 5. Note the serial number of your HP-ID Module. Replace the dots in step 9 with this serial number. Your HP-ID-Module is no longer needed.
- 6. Switch the system on and load your operating system.
- 7. If your keyboard is set to capitalization, shift into small-letter mode using the "Caps"-key (next to "CTRL"). Small letters will now be printed. For capitalization, one has to press the "shift"-key.
- 8. Switch the toggle-switch at the front panel of the SYSKOMP-ID-BOX to the left, into position "Learn". Do not be irritated by the fact that the keyboard has been disconnected from the computer and that subsequent keystrokes will not be displayed on the screen.

- 9. Type <u>Test?=46084A...A....</u> on the keyboard. Replace the dots ("...A....") with the serial number of your HP-ID-Module (see step 5).
- 10. Switch the toggle-switch at the front panel of the SYSKOMP-ID-BOX back to the right, into "Normal" position.

Now your input will appear on the screen without a question mark. If you have made a typing error and a different message is displayed, repeat steps 7 to 10.

11. Load and start your software.

Now the SYSKOMP-ID-BOX is functioning in place of your HP-ID-Module. Your software can be used as usual. You will find a detailed description of all of the possibilities of the SYSKOMP-ID-BOX in the following sections. As the installation of the SYSKOMP-ID-BOX has already been performed, you can skip chapter 2 ("Installation") and continue with chapter 3 ("Setting serial numbers").